

# EXCENTR DAILY X1

*Operating and maintenance instructions*



**EXCENTR METHOD**  
THE CLEANING TECHNIQUE OF THE FUTURE



AMPÈREWEG 12  
4631 SP HOOGERHEIDE  
T. 088 1700 501  
INFO@EXCENTR.COM  
WWW.EXCENTR.COM



01 Remove both batteries from the machine.



02 Replace the batteries in the charger – and start charging.



03 Remove the recovery tank from the machine and empty it into a drain or sink.



04 Rinse both the recovery tank and the filter thoroughly with cold water.



05 Note: the filter has a notch that fits into the recess of the recovery tank.



06 Remove the clean water tank from the machine and empty it into a drain or sink.



Rinse both the clean water tank and the filter thoroughly with cold water.



Note: the filter is located on the opposite side of the clean water tank.



Detach the hose, feed it through the hole, and then remove the squeegee.



Flush the hose and remove the squeegee blades from the squeegee. Rinse them with cold water.



Remove the brushes from the machine and rinse them thoroughly under cold water.



**VIDEO:**  
HOW TO USE



**VIDEO:**  
MAINTENANCE